

ADAPTOR KIT for (to be used with STM-007-01, BBZ-001 & AGP-001)

## **IMPORTANT:**

This adaptor kit is to be used in conjunction with the instructions and handguard kit *STM-007-01*, *BBZ-001* & *AGP-001*.

## **INSTRUCTIONS:**

- Ensure bolt M8x40mm or M8x45mm Flat Head is used.
- A medium thread locking compound applied to the Threaded Adaptor (15) is recommended.
- Remove Original bar end weight.
- Insert the Threaded Adaptor (15).
- Tighten threaded adaptor (15) into the handlebar to 20 Nm (14.8 lbf ft).



